


# WALK BEHIND FLOOR SAW



**Model: FS350H/FS350Z  
FS480H/ FS480Z**



## Operator's Manual

***MechMaxx***

[www.mechmaxx.com](http://www.mechmaxx.com)



## TABLE OF CONTENTS

|                                            |           |                                      |           |
|--------------------------------------------|-----------|--------------------------------------|-----------|
| <b>TABLE OF CONTENTS</b>                   | <b>1</b>  | <b>PARTS DIAGRAM (Q350 ASSEMBLY)</b> | <b>18</b> |
| <b>SPECIFICATIONS</b>                      | <b>2</b>  | <b>PARTS LIST (Q350 ASSEMBLY)</b>    | <b>19</b> |
| <b>SAFETY LABELS</b>                       | <b>4</b>  | <b>PARTS DIAGRAM (Q480 ASSEMBLY)</b> | <b>22</b> |
| LABEL LOCATIONS                            | 4         | <b>PARTS LIST (Q480 ASSEMBLY)</b>    | <b>23</b> |
| SAFETY LABELS                              | 4         |                                      |           |
| OPERATING LABELS                           | 4         |                                      |           |
| <b>RULES FOR SAFE OPERATION</b>            | <b>7</b>  |                                      |           |
| GENERAL SAFETY                             | 7         |                                      |           |
| DIAMOND BLADE SAFETY                       | 8         |                                      |           |
| FLOOR SAW TRANSPORTATION SAFETY            | 8         |                                      |           |
| EMERGENCIES                                | 8         |                                      |           |
| MAINTENANCE SAFETY                         | 9         |                                      |           |
| <b>OPERATION</b>                           | <b>10</b> |                                      |           |
| INTRODUCTION/DETERMINING THE RIGHT MACHINE | 10        |                                      |           |
| OPERATING PRINCIPLE                        | 10        |                                      |           |
| DELIVERY CHECKS                            | 10        |                                      |           |
| INSTALLING BLADE                           | 10        |                                      |           |
| TYPES OF CUTTING                           | 11        |                                      |           |
| BEFORE STARTING                            | 11        |                                      |           |
| COLD START                                 | 11        |                                      |           |
| HOT START                                  | 11        |                                      |           |
| TO START CUTTING                           | 11        |                                      |           |
| CUTTING                                    | 12        |                                      |           |
| BELTS & PULLEYS                            | 12        |                                      |           |
| DRY CUTTING                                | 13        |                                      |           |
| <b>MAINTENANCE - TROUBLESHOOTING</b>       | <b>14</b> |                                      |           |
| <b>LUBRICATION AND SERVICE</b>             | <b>17</b> |                                      |           |
| <b>TRANSPORTATION</b>                      | <b>17</b> |                                      |           |

## SPECIFICATIONS

| Model                     | FS350H                                                     | FS350Z                    |
|---------------------------|------------------------------------------------------------|---------------------------|
| Engine                    | Honda GX160                                                | Zonsen GB210              |
| Engine Type               | Single-Cylinder, 4-Stroke, Air-Cooled, OHV Gasoline Engine |                           |
| Engine Displacement       | 163 cc                                                     | 208 cc                    |
| Horsepower                | 4.8 HP (3.6kW) @ 3600 RPM                                  | 5.8 HP (4.3kW) @ 3600 RPM |
| Start System              | Recoil                                                     |                           |
| Fuel Tank Capacity        | 3.3 US qt (3.1L)                                           | 2.8 US qt (2.6L)          |
| Engine Oil Capacity       | 0.61 US qt (0.6L)                                          |                           |
| Blade Diameter            | 14 in                                                      |                           |
| Max Cutting Depth         | 4 in                                                       |                           |
| Arbor Diameter            | 1 in                                                       |                           |
| Water Tank Capacity       | 3.2 US gal                                                 |                           |
| Overall Dimension (LxWxH) | 35 x 19 x 34 in                                            |                           |
| Weight                    | 143/lbs                                                    |                           |

| Model                     | FS480H                                                     | FS480Z                    |
|---------------------------|------------------------------------------------------------|---------------------------|
| Engine                    | Honda GX390                                                | Zonsen GB460B             |
| Engine Type               | Single-Cylinder, 4-Stroke, Air-Cooled, OHV Gasoline Engine |                           |
| Engine Displacement       | 389 cc                                                     | 459 cc                    |
| Horsepower                | 11.7 HP (8.7kW) @ 3600 RPM                                 | 15.0 HP (11kW) @ 3600 RPM |
| Start System              | Recoil                                                     |                           |
| Fuel Tank Capacity        | 6.4 US qt (6.1 L)                                          | 6.3 US qt (6 L)           |
| Engine Oil Capacity       | 1.16 US qt (1.1 L)                                         |                           |
| Blade Diameter            | 20 in                                                      |                           |
| Max Cutting Depth         | 7 in                                                       |                           |
| Arbor Diameter            | 1 in                                                       |                           |
| Water Tank Capacity       | 7.9 US gal                                                 |                           |
| Overall Dimension (LxWxH) | 44 x 20 x 37 in                                            |                           |
| Weight                    | 231lbs                                                     | 243lbs                    |

Specifications are subject to change without notice.

Engine specifications may vary by configuration. Refer to the engine manufacturer's manual for engine-specific service information.

## SAFETY LABELS

### LABEL LOCATIONS




### SAFETY LABELS

The machines use international pictorial labels where needed. These labels are described below:



**NOTE:** These molded-in label contains important safety and operating information. If the label becomes illegible, replace it immediately. Contact MechMaxx or an authorized service dealer for replacement labels.

| Label | Meaning                                                                                                                                                                                                                                                                                                                                                                |
|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p><b>DANGER!</b> Wear appropriate PPE including gloves, eye protection, hearing protection, and safety footwear.</p> <p>Do not touch the engine or muffler during or immediately after operation—hot surfaces may cause burns.</p> <p>Keep hands and feet away from moving parts.</p> <p>Operate only in well-ventilated areas to avoid carbon monoxide exposure.</p> |
|       | <p><b>WARNING!</b> Before use, fill the fuel tank with gasoline and add engine oil to the proper level.</p> <p>Operating the engine with low or no oil will cause permanent engine damage and may void the warranty.</p> <p>Refer to the engine manual for detailed instructions.</p>                                                                                  |

| Label                                                                               | Meaning                                                                                                                                                                                                                                                                                                                                                       |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <p><b>CAUTION!</b> Read the operator's manual before operating the machine. Transport only in the upright position. Keep unauthorized persons away from the equipment. Ensure all safety devices are in place before starting the engine. Stop the engine and allow it to cool before servicing or refueling. Never leave the machine running unattended.</p> |
|    | <p><b>WARNING!</b> Keep hands and feet clear of the blade and all moving parts during operation. Contact with moving parts may cause serious injury.</p>                                                                                                                                                                                                      |
|    | <p><b>NOTICE:</b> Use the blade depth control to raise or lower the blade.</p>                                                                                                                                                                                                                                                                                |
|  | <p><b>WARNING!</b> Before moving the machine outside the cutting area, make sure the blade is raised and the cutting tool has stopped rotating.</p>                                                                                                                                                                                                           |
|  | <p><b>CAUTION!</b> Read the operator's manual for machine information.</p>                                                                                                                                                                                                                                                                                    |
|  | <p><b>DANGER!</b> Keep sparks, flames, and hot materials away from the machine.</p>                                                                                                                                                                                                                                                                           |
|  | <p><b>CAUTION!</b> Lifting point.</p>                                                                                                                                                                                                                                                                                                                         |

## OPERATING LABELS

The machines use international pictorial labels where needed. These labels are described below:

| Label                                                                              | Meaning                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | <p>START THE ENGINE</p> <ol style="list-style-type: none"> <li>1. Turn the engine switch to the ON position</li> <li>2. Close the choke</li> <li>3. Pull the recoil starter</li> <li>4. Open the choke.</li> </ol> |
|   | <p>Stop the engine:<br/>Turn the engine switch to OFF position.</p>                                                                                                                                                |
|  | <p>Throttle control lever:<br/>Turtle = Idle or Slow<br/>Rabbit = Full or Fast</p>                                                                                                                                 |

## RULES FOR SAFE OPERATION

**WARNING:**

Failure to follow instructions in this manual may lead to serious injury or even death! This equipment is to be operated by trained and qualified personnel only! This equipment is for industrial use only.

The following safety guidelines should always be used when operating these Floor Saws:

### GENERAL SAFETY

- DO NOT operate or service this equipment before reading the entire manual.
- This equipment should not be operated by persons under 18 years of age.
- NEVER operate this equipment without proper protective clothing, shatterproof glasses, steel-toed boots and other protective devices required by the job.
- NEVER operate this equipment when not feeling well due to fatigue, illness or taking medicine.
- NEVER operate this equipment under the influence of drugs or alcohol.
- NEVER use accessories or attachments, which are not recommended by our company for this equipment. Damage to the equipment and/or injury to user may result.
- The manufacturer does not assume responsibility for any accident due to equipment modifications.
- Whenever necessary, replace nameplate, operation and safety decals when they become difficult to read.
- ALWAYS check the machine for loosened threads or bolts before starting.
- NEVER touch the hot exhaust manifold, muffler or cylinder. Allow these parts to cool before servicing engine or saw.
- High Temperatures – Allow the engine to cool before adding fuel or performing service and maintenance functions. Contact with hot components can cause serious burns.
- The engine section of this saw requires an adequate free flow of cooling air. NEVER operate the saw in any enclosed or narrow area where free flow of the air is restricted. If the air flow is restricted it will cause serious damage to the saw or engine and may cause injury to people. Remember the saw's engine gives off DEADLY carbon monoxide gas.
- ALWAYS refuel in a well-ventilated area, away from sparks and open flames.
- ALWAYS use extreme caution when working with flammable liquids. When refueling, stop the engine and allow it to cool. DO NOT smoke around or near the machine. Fire or explosion could result from fuel vapors, or if fuel is spilled on a hot engine.
- NEVER operate the saw in an explosive atmosphere or near combustible materials. An explosion or fire could result causing severe bodily harm or even death.
- Topping-off to the fuel filler port is dangerous, as it tends to spill fuel.
- NEVER use fuel as a cleaning agent.
- ALWAYS read, understand, and follow procedures in operator's Manual before attempting to operate equipment.
- ALWAYS be sure to operator is familiar with proper safety precautions and operating techniques before using the saw.
- Stop the engine when leaving the saw unattended.
- Block the unit when leaving or when using on a slope.
- Maintain this equipment in a safe operating condition at all times.
- ALWAYS stop the engine before servicing, adding fuel and oil.
- NEVER run engine without air filter. Severe engine damage may occur.
- ALWAYS service air cleaner frequently to prevent carburetor malfunction.

- ALWAYS store equipment properly when it is not being used. Equipment should be stored in a clean, dry location out of the reach of children.
- NEVER operate this cutter in areas that contain combustible material or fumes. Fire and/or explosions may result from errant sparks from the equipment.

**WARNING:**

- DO NOT operate this equipment unless all guards and safety devices are attached and in place.
- Caution must be exercised while servicing this equipment. Rotating and moving parts can cause injury if contacted.
- Keep all inexperienced and unauthorized people away from the equipment at all times.
- Unauthorized equipment modifications will void all warranties.

## DIAMOND BLADE SAFETY

- Use appropriate steel centered diamond blades manufactured for use on Floor Saws.
- ALWAYS inspect diamond blades before each use. The blade should exhibit no cracks, dings, or flaws in the steel centered core and/or rim. Center (arbor) hole must be undamaged and true.
- Examine blade flanges for damage, excessive wear and cleanliness before mounting blade. Blade should fit snugly on the shaft and against the inside/outside blade flanges.
- Ensure that the blade is marked with an operating speed greater than the blade shaft speed of the saw.
- Only cut the material that is specified by the diamond blade. Read the specifications of the diamond blade to ensure the proper tool has been matched to the material being cut.
- ALWAYS keep blade guards in place. Exposure of the diamond blade must not exceed 180 degrees.
- Ensure that the diamond blade does not come into contact with ground or surface during transportation. DO NOT drop the diamond blade on ground or surface.
- The engine governor is designed to permit maximum engine speed in a no-load condition. Speeds that exceed this limit may cause the diamond blade to exceed the maximum safe allowable speed.
- Ensure that the blade is mounted for proper operating direction.

## FLOOR SAW TRANSPORTATION SAFETY

- Use the lifting bail and appropriate lifting equipment to ensure the safe movement of the saw.
- DO NOT use the handle bars and/or front pointer as lifting points.
- NEVER tow the saw behind a vehicle.
- Ensure that both pointer bars are positioned appropriately to minimize their exposure during transportation.
- Safeguard against extreme saw attitudes relative to level. Engines tipped to extreme angles may cause oil to gravitate into the cylinder head making the engine difficult to start.
- NEVER transport the saw with the blade mounted.

## EMERGENCIES

- ALWAYS know the location of the nearest fire extinguisher and first aid kit. Know the location of the nearest telephone. Also know the phone numbers of the nearest ambulance, doctor and fire department. This information will be invaluable in the case of an emergency.

**MAINTENANCE SAFETY**

- NEVER lubricate components or attempt service on a running machine.
- ALWAYS allow the machine a proper amount of time to cool before servicing.
- Keep the machinery in running condition.
- Fix damage to the machine immediately and always replace broken parts.
- Dispose of hazardous waste properly. Examples of potentially hazardous waste are used motor oil, fuel and fuel filters.
- DO NOT use food or plastic containers to dispose of hazardous waste.

## OPERATION

### INTRODUCTION/DETERMINING THE RIGHT MACHINE

Congratulations on your purchase of our saw! You've made an excellent choice! Our floor saw has been specifically designed as the ideal machine for the professional contractor who is engaged in concrete and asphalt flat cutting.

The machines used for the primary purpose of "flat" cutting.

This type of cutting is described as "flat" because the pavement is cut somewhere close to a horizontal plane. It is the most common type of diamond blade cutting.

Floor saws in the industry are available in a variety of types, sizes and styles, they range from manual or self propelled in horsepower from 7-72hp. It is possible to cut both concrete (green or cured, with or without rebar) or asphalt with a floor saw. Our saw utilized for jobs requiring precision cutting including floors, pavements, walkways, ramps and other flat sawing applications.

You will find a saw to fit a wide variety of job applications.

Upon receipt of your machine, CAREFULLY CHECK FOR ANY FREIGHT DAMAGE. Any damage should be immediately reported to the carrier and a claim registered.

### OPERATING PRINCIPLE

The following instructions were compiled to provide you information on how to obtain long and trouble free use of the unit. Periodic maintenance of this unit is essential. Read the manual in its entirety and follow the instructions carefully. Failure to do so may injure yourself or a bystander.

### DELIVERY CHECKS

Immediately upon taking delivery of your new equipment and before putting it into service:

- Read the handbook completely—it could save a great deal of unnecessary expense.
- Read the engine manual supplied.
- Check the general condition of the equipment—has it been damaged during delivery?
- Check engine oil level.
- Check fuel levels.

Recommend lubricants are detailed in the CARE AND MAINTENANCE section.

### INSTALLING BLADE

1. Be certain that the spark plug wire is disconnected before installing the blade.
2. Remove the blade shaft nut, and take off outside blade shaft flange.
3. Clean off any foreign particles on the clamping surfaces of flanges and on the mounting surface of the blade.
4. Place the blade on the blade shaft, lining up the offset drive pin in the blade with the drive pin in the mounting collar (if the pin system is available on the machine). If your blade has a directional rotational arrow, position arrow for down cut (diamond tail trailing for down cut).
5. Replace the outside blade shaft flange on the blade shaft. Drive pin on the inside collar must project through the drive hole in the blade and into the outside collar (if the pin system is available on the machine).
6. Tighten the blade shaft nut securely against star washer and outside flange, using wrench supplied.
7. Reconnect the spark plug wire after installation is complete.

## TYPES OF CUTTING

Cut speed depends entirely on using the correct blade for the material to be cut. Wet or dry, diamond blades of various specifications are available for cutting concrete or asphalt.

## BEFORE STARTING

1. Use correct blade for cutting conditions.
2. Ensure arbors and flanges are clean and undamaged.
3. Mount blade and tighten securely using wrench.
4. When wet cutting, check water jets for adequate flow.
5. Align pointer with cutter blade.



### CAUTION

Set unit up in an open area. Avoid close proximity to structures or other equipment. Failure to do so may cause inadvertent injury to operator or other persons in the area.

## COLD START

Open the fuel valve under the gas tank all the way. Position the engine stop switch, located on the engine, to run. Open the throttle approximately half way and apply the choke. Pull the starter rope sharply. When the engine starts, open the choke and adjust the throttle as necessary to keep it running. Allow the engine to warm up for a few minutes before placing it under the load. If the engine doesn't start after (3) pulls, open choke slightly to prevent flooding. Always operate the engine at full throttle when under load.

## HOT START

Open the valve under the gas tank all the way if it has been shut off. Open the throttle approximately half way. Do not apply the choke. Pull the starter rope sharply until the engine starts. When the engine starts, adjust the throttle. Always operate the engine at full throttle when under load.

**NOTE:** These starting instructions are general guidelines only. Since many engine options are available, consult the Engine Manual included with this unit for specific instructions.



### CAUTION

Gasoline Engines – To improve the engine service life, allow the engine to idle without load for (2) to (5) minutes before shutting it down. When the idling period is up, use the stop switch located on the engine and turn it to stop. Close the fuel valve under the gas tank. Engine flooding can occur if the valve is left open during transport.

## TO START CUTTING

1. Start engine and let engine warm up. All cutting is done at full throttle.
2. Align blade and saw with cut. If wet cutting, open water valve and turn water safety switch on.
3. Push and guide the saw manually using the handles. This machine is not self-propelled and does not have powered forward or reverse travel. Keep both hands on the handles and maintain full control of the saw while following the cutting line.
4. Lower blade into cut slowly.
5. Cut as fast as blade will allow. If blade climbs out of cut, reduce forward speed or depth of cut.
6. Use only enough side pressure on saw handles to follow cutting line.

## CUTTING

Lower the blade into concrete to required depth by turning the tilt crank counterclockwise. Ease the saw slowly forward. Slow forward pressure if the saw begins to stall.

**NOTE:** For deeper cuts (4 inches/102mm or more), several cuts should be made in incremental steps of 1-1/2 inch (38mm) to 2 inches (51mm) until the desired depth is reached.

Push the saw steadily forward using the front pointer as a guide. Exert enough forward pressure so that the engine/motor begins to labor, but does not slow down. If the saw begins to stall, retard forward movement until full RPM is restored to the blade. If saw stalls, raise the blade out of the cut before restarting. Avoid excessive side pressure or twisting of the blade in the cut.

## BELTS & PULLEYS

### NEVER MAKE ADJUSTMENTS TO V-BELTS AND PULLEYS WHILE ENGINE IS RUNNING.

1. The best tension for a v-belt drive is the lowest tension at which the belts will not slip under full load.
2. Take up tension until the belts are snug in the grooves. Run the drive for about five (5) minutes to "seat" the belts. Then impose the peak load. If the belts slip, tighten them until they no longer slip at peak load. Most new belts will need additional tensioning after seating.
3. Remember, too much tension shortens belt and bearing life.
4. Check the belt tension frequently during the first day of operation. Check the belt tension periodically thereafter and make any necessary adjustments.
5. The two most common causes of sheave misalignment are:
  - a) The engine drive shaft and the blade shaft are not parallel.
  - b) The pulleys are not located properly on the shafts.
6. To check alignment, use a steel straight edge. See Figure 1.
7. Line up the straight edge along the outside face of both pulleys shown in the drawing. All pulleys have (2) set screws in the bottom of their grooves. Set screws require thread locking lock title.
8. Misalignment will show up as a gap between the pulley face and straight edge. Make sure there is clearance between arbor pulley and saw base on both sides.





Figure 1

**DRY CUTTING**

- Never operate any saw without safety guards in place.
- Do not exceed maximum operating speed established for blade diameter.
- Do not force blade into material: allow blade to cut at its own speed.
- Do not make long continuous cuts. Never dry cut for more than 30 seconds at a time. Allow blade to cool.
- Do not cut or grind with side of blade or cut a curve or radius. Do not cut dry with blades recommended for wet cutting.
- Do not operate saw with blade diameter larger than machine's capacity.

## MAINTAINANCE - TROUBLESHOOTING

| PROBLEM                                                                                                      | CAUSE                                                                                                                                                                                                                                                                                                                                                                                   | REMEDY                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>UNEVEN SEGMENT WEAR</p>  | <ul style="list-style-type: none"> <li>• (In wet cutting) Insufficient water (usually on one side of blade).</li> <li>• Equipment defects also can cause the segments to wear unevenly.</li> <li>• Saw head is misaligned.</li> </ul>                                                                                                                                                   | <ul style="list-style-type: none"> <li>• Flush water system.</li> <li>• Check flow to both sides of blade.</li> <li>• Replace bad bearings, worn arbor shaft or misalignment to spindle.</li> <li>• Check alignment for squareness, both vertically and horizontally, of the saw blade.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <p>SEGMENT CRACKS</p>       | <ul style="list-style-type: none"> <li>• Blade is too hard for material being cut.</li> </ul>                                                                                                                                                                                                                                                                                           | <ul style="list-style-type: none"> <li>• Use a blade with a softer bond/matrix.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <p>SEGMENT LOSS</p>        | <ul style="list-style-type: none"> <li>• Blade overheats because of lack of coolant (water or air).</li> <li>• Core is worn from undercutting.</li> <li>• Defective collars/flanges set blade out of alignment.</li> <li>• Blade is too hard for material being cut.</li> <li>• Blade is cutting out of round, causing a pounding motion.</li> <li>• Improper blade tension.</li> </ul> | <ul style="list-style-type: none"> <li>• (Wet Cutting) Check water lines.</li> <li>• Make sure flow is adequate on both sides of blade and there are no blockages</li> <li>• Use sufficient water to flush out the cut.</li> <li>• (Dry Cutting) Run blade free of cut periodically to air cool.</li> <li>• Clean collars/flanges or replace if they are under recommended diameter.</li> <li>• Use proper blade specification for material being cut.</li> <li>• Replace worn bearings; realign blade shaft or replace worn blade mounting arbor.</li> <li>• When ordering blades match shaft speed of saw.</li> <li>• Check spindle speed to ensure blade is running at correct RPM.</li> <li>• Avoid twisting or turning blade in the cut.</li> </ul> |
| <p>CRACKS IN CORE</p>     | <ul style="list-style-type: none"> <li>• Blade flutters in cut as a result of losing blade tension.</li> <li>• Blade specification is too hard for the material being cut.</li> </ul>                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>• Tighten the blade shaft nut.</li> <li>• Make sure blade is running at proper speed and that drive pin is functioning properly.</li> <li>• Use a softer bond/matrix to eliminate stress.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

| PROBLEM                                                                                                            | CAUSE                                                                                                                                                                                                                                                                                                                              | REMEDY                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>LOSS OF TENSION</p>            | <ul style="list-style-type: none"> <li>• Core overheating.</li> <li>• Core overheating as a result of blade spinning on arbor.</li> <li>• Core overheating from rubbing the material being cut.</li> <li>• Unequal pressure at blade clamping collars/flanges.</li> <li>• Blade is too hard for the material being cut.</li> </ul> | <ul style="list-style-type: none"> <li>• Make certain blade RPM is correct.</li> <li>• Check water flow, distribution and lines.</li> <li>• Tighten the blade shaft nut. Make certain the drive pin is functioning.</li> <li>• Properly align the saw to square cut.</li> <li>• Collars/flanges must be identical in diameter and the recommended size.</li> <li>• Use a softer bond/matrix to reduce stress.</li> </ul> |
| <p>BLADE WOBBLER</p>             | <ul style="list-style-type: none"> <li>• Blade is on a damaged or worn saw.</li> <li>• Worn collar.</li> <li>• Blade runs at an incorrect speed.</li> <li>• Collar/flange diameters are not identical.</li> <li>• Blade is bent as a result of dropping or twisting.</li> </ul>                                                    | <ul style="list-style-type: none"> <li>• Check for bad bearings, bent shaft, or worn mounting arbor.</li> <li>• Check collars/flanges to make sure they are clean, flat and of correct diameter.</li> <li>• Set engine at proper RPM.</li> <li>• Use proper size blade collars/flanges.</li> <li>• DO NOT use bent blade. Contact blade manufacturer.</li> </ul>                                                         |
| <p>BLADE WILL NOT CUT</p>       | <ul style="list-style-type: none"> <li>• Blade is too hard for material being cut.</li> <li>• Blade has become dull.</li> <li>• Blade does not cut material it was specified for.</li> </ul>                                                                                                                                       | <ul style="list-style-type: none"> <li>• Select proper blade for material being cut.</li> <li>• Sharpen by cutting on softer abrasive material to expose diamonds. If continually sharpening, the blade is too hard for the material being cut.</li> <li>• Break-in on the material to be cut. If it does not dress itself, sharpen as you would a dull blade.</li> </ul>                                                |
| <p>UNDERCUTTING THE CORE</p>    | <ul style="list-style-type: none"> <li>• Abrasive wearing of the core faster than the segments.</li> </ul>                                                                                                                                                                                                                         | <ul style="list-style-type: none"> <li>• Use water to flush out fines generated during cutting</li> <li>• Use wear-resistant cores.</li> </ul>                                                                                                                                                                                                                                                                           |
| <p>ARBOR HOLE OUT-OF-ROUND</p>  | <ul style="list-style-type: none"> <li>• Collars/flanges are not properly tightened, permitting blade to rotate or vibrate on the shaft.</li> <li>• Collars/flanges are worn or dirty. Blade is not properly mounted.</li> </ul>                                                                                                   | <ul style="list-style-type: none"> <li>• Make certain the blade is mounted on the proper shaft diameter. Tighten the shaft nut with a wrench to make certain that the blade is secure.</li> <li>• Clean collars/flanges, make sure they are not worn. Tighten arbor nut.</li> <li>• Make sure the pin hole slides over drive pin.</li> </ul>                                                                             |

| PROBLEM                                                                                                          | CAUSE                                                                                                                                                                                                                                                                                                                              | REMEDY                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>BLADE WORN OUT OF ROUND</p>  | <ul style="list-style-type: none"> <li>• Core overheating.</li> <li>• Core overheating as a result of blade spinning on arbor.</li> <li>• Core overheating from rubbing the material being cut.</li> <li>• Unequal pressure at blade clamping collars/flanges.</li> <li>• Blade is too hard for the material being cut.</li> </ul> | <ul style="list-style-type: none"> <li>• Install new blade shaft bearings or blade shaft, as required.</li> <li>• Tune engine according to manufacturer's manual.</li> <li>• If core is worn or arbor hole damaged, DO NOT USE. Contact blade manufacturer.</li> <li>• Replace worn shaft or mounting arbor bushing.</li> <li>• Make certain that drive pin is functioning.</li> <li>• Tighten spindle nut.</li> </ul> |

---

## LUBRICATION AND SERVICE

---

- Check oil levels, wiring, hoses (air, fuel, water) and lubricate machine daily.
- Repair or replace all worn or damaged components immediately.
- Check drive belt tension, do not over-tension.
- Make sure machine has full set of matched belts.
- Check blade shaft, make sure arbor and threads are not worn, damaged, or bent.
- Blade shaft bearings should be tight, no free play side-to-side or up and down.
- Grease blade shaft bearings daily.
- Blade collars should be clean, free of nicks and burrs. No diameter wear and not out of round.
- Drive pin not excessively worn or bent and free of gouges.
- All guards in place and secure.
- All fasteners tight and secure.
- Air filter/oil filter (hydraulic or engine) clean.
- Flush clean water through the pump and spray the assembly every night. This prolongs the pump and blade life.

Lubricants:

Engine Oil SAE 10W/30

General Grease #1 Lithium

- Clean machine before starting lubrication maintenance.
- Insure machine is on solid, level ground before starting maintenance.
- During lubrication maintenance insure strict cleanliness is observed at all times.
- To avoid the risk of accidents, use the correct tool for the job and keep tools clean.
- The draining of engine oil is best carried out when the oil is warm NOT hot.
- Any spilled oil must be cleaned up immediately.
- Use only clean containers for oil and only CLEAN, FRESH oils and grease of correct grade.
- Contaminated Water/Fluids/Oils/Filters must Be Disposed of Safely.


---

## TRANSPORTATION

---

1. Always shut off engine when transporting machine.
2. Make sure lifting device has enough capacity to hold machine (see identification plate on machine for weight).
3. Use lifting point when lifting machine.
4. Trolley wheel as optional is used for short distance transportation.

## PARTS DIAGRAM (FS350Z/FS350H ASSEMBLY)




**PARTS LIST (FS350Z/FS350H ASSEMBLY)**

| No. | Description          | Specification | Qty. |
|-----|----------------------|---------------|------|
| 1   | bolt                 | M8*25         | 5    |
| 2   | spring washer        | Ø8            | 10   |
| 3   | flat washer          | Ø8            | 2    |
| 4   | flat key             | 8*35          | 1    |
| 5   | rod shaft pulley     |               | 1    |
| 6   | bearing block        | UCP206        | 2    |
| 7   | bolt                 | M10*40        | 4    |
| 8   | flat washer          | Ø10           | 9    |
| 9   | Blade shaft          |               | 1    |
| 10  | flat key             | 5*16          | 1    |
| 11  | Blade clip           | Ø50/25.4      | 1    |
| 12  | blade                | Ø50           | 1    |
| 13  | flat washer          | Φ18           | 1    |
| 14  | spring washer        | Φ18           | 1    |
| 15  | nut                  | M18*2.5       | 1    |
| 16  | nut                  | M10           | 4    |
| 17  | blade cover assembly |               | 1    |
| 18  | splash guard         |               | 1    |
| 19  | nut                  | M8            | 2    |
| 20  | bolt                 | M6*12         | 2    |
| 21  | bolt                 | M10*20        | 3    |
| 22  | nylon wheel          | Ø125*12*35    | 1    |
| 23  | nut                  | M10           | 3    |
| 24  | guide set            |               | 1    |
| 25  | bolt                 | M10*100       | 1    |
| 26  | guide rod            |               | 1    |
| 27  | engine               |               | 1    |
| 28  | V-belt               | 13*584        | 2    |
| 29  | Engine pulley        |               | 1    |

| No. | Description             | Specification | Qty. |
|-----|-------------------------|---------------|------|
| 30  | flat key                | 5*40          | 1    |
| 31  | flat washer             | Ø8            | 13   |
| 32  | flat washer             | 8*28*2        | 6    |
| 33  | bolt                    | M8*40         | 4    |
| 34  | belt cover              |               | 1    |
| 35  | Belt baffle             |               | 1    |
| 36  | spring washer           | Ø10           | 60   |
| 37  | bolt                    | M10*40        | 4    |
| 38  | bolt                    | M10*25        | 4    |
| 39  | nut                     | M8            | 2    |
| 40  | bolt                    | M8*60         | 2    |
| 41  | mainframe               |               | 1    |
| 42  | bolt                    | M10*20        | 3    |
| 43  | rubber plug             |               | 2    |
| 44  | Water tank              | C80T          | 1    |
| 45  | cover of water tank     |               | 1    |
| 46  | rubber plug             |               | 4    |
| 47  | switch                  |               | 1    |
| 48  | bolt                    | M5*16         | 2    |
| 49  | nut                     | M5            | 2    |
| 50  | bolt                    | M8*25         | 2    |
| 51  | bolt                    | M8*50         | 1    |
| 52  | Fender bracket          |               | 1    |
| 53  | bolt                    | M8*25         | 5    |
| 54  | Water pipe              | 0.3m          | 1    |
| 55  | copper valve            | C80T          | 1    |
| 56  | Throttle level assembly | 0.9           | 1    |
| 57  | handle                  |               | 1    |
| 58  | Handle cover            | 0.55          | 1    |
| 59  | Folded handle           |               | 1    |
| 60  | bearing block           | LF205         | 1    |

| No. | Description           | Specification | Qty. |
|-----|-----------------------|---------------|------|
| 61  | bolt                  | M8*40         | 4    |
| 62  | External hexagon bolt | M8*30         | 1    |
| 63  | Screw stem            |               | 1    |
| 64  | lifting poker         |               | 1    |
| 65  | nut                   | M16           | 2    |
| 66  | flat washer           | Ø16           | 4    |
| 67  | bolt                  | M16*40        | 2    |
| 68  | Walk round frame      |               | 1    |
| 69  | Black aluminium wheel | Ø125*50       | 2    |
| 70  | Shaft card            | Ø20           | 4    |
| 71  | gasket                | 20mm          | 2    |
| 72  | Black aluminium wheel | Ø180*50       | 2    |
| 73  | rubber mat            |               | 1    |
| 74  | rear axle shaft       |               | 1    |

## PARTS DIAGRAM (FS480Z/FS480H ASSEMBLY)



**PARTS LIST (FS480Z/FS480H ASSEMBLY)**

| No. | Description                                | Specification | Qty. |
|-----|--------------------------------------------|---------------|------|
| 1   | external hexagon bolt and flat gasket      | M10*25        | 20   |
| 2   | belt cover for engine                      | Q480-00-003   | 1    |
| 3   | Frame Left plate                           |               | 1    |
| 4   | external hexagon thin bolt and flat gasket | M10*20        | 1    |
| 5   | belt                                       |               | 1    |
| 6   | key                                        | 8*40          | 1    |
| 7   | pulley for blade                           | Q480-00-038   | 1    |
| 8   | key                                        | 7*40          | 1    |
| 9   | pulley for engine                          | Q480-00-021   | 1    |
| 10  | engine                                     |               | 1    |
| 11  | external hexagon bolt,flat gasket and nut  | M10*55        | 4    |
| 12  | protective frame                           | Q480-00-004   | 1    |
| 13  | frame                                      | Q480-00-034   | 1    |
| 14  | external hexagon bolt and nut              | M10*50        | 2    |
| 15  | external hexagon bolt and falt gasket      | M10*40        | 1    |
| 16  | guard                                      | Q480-00-013   | 1    |
| 17  | external hexagon bolt and gasket           | M10*100       | 2    |
| 18  | Nylon wheels                               | Ø125*12*35    | 1    |
| 19  | nut                                        | M10           | 6    |
| 20  | flat gasket                                | φ10           | 3    |
| 21  | point wheel                                | Q480-00-010   | 1    |
| 22  | external hexagon bolt and falt gasket      | M10*35        | 1    |
| 23  | Handle supportor                           |               | 2    |
| 24  | external hexagon bolt and falt gasket      | M10*25        | 10   |
| 25  | locked nut and flat gasket                 | M10           | 14   |
| 26  | bearing                                    | UCFLU206      | 2    |
| 27  | shaft                                      | Q480-00-031   | 1    |
| 28  | key                                        | 8*25          | 1    |
| 29  | balde flange                               | Q480-00-020   | 1    |

| No. | Description                             | Specification | Qty. |
|-----|-----------------------------------------|---------------|------|
| 30  | blade                                   |               | 1    |
| 31  | clamp                                   | Q480-00-002   | 1    |
| 32  | flat gasket                             | Ø22           | 1    |
| 33  | spring gasket                           | Ø22           | 1    |
| 34  | nut                                     | M22*2.5       | 1    |
| 35  | external hexagon bolt and falt gasket   | M8*20         | 3    |
| 36  | rubber wheel                            | Ø125*50       | 2    |
| 37  | lifting supporter                       | Q480-00-037   | 1    |
| 38  | axle bearing supporter                  | Q480-00-035   | 2    |
| 39  | internal hexagon bolt                   | M8*20         | 1    |
| 40  | external hexagon bolt and spring gasket | M12*35        | 2    |
| 41  | enlarge flat gasket                     | Ø12           | 2    |
| 42  | fender                                  | Q480-00-033   | 2    |
| 43  | rear wheel                              | Ø200*50       | 2    |
| 44  | Flange bolt                             | M8            | 4    |
| 45  | key                                     | 6*20          | 1    |
| 46  | blade cover                             | Q480-00-016   | 1    |
| 47  | lifter seat                             |               | 1    |
| 48  | fender                                  | Q480-00-015   | 1    |
| 49  | lifter seat                             |               | 2    |
| 50  | bearing                                 | UCFLU204      | 1    |
| 51  | countersunk head bolt                   | M6*16         | 2    |
| 52  | tube                                    | Ø17*12        | 1    |
| 53  | connector                               |               | 1    |
| 54  | water tank                              | 250*250*500   | 1    |
| 55  | water tank cap                          |               | 1    |
| 56  | external hexagon bolt and spring gasket | M10*20        | 6    |
| 57  | nut and spring gasket                   | M8            | 2    |
| 58  | protective frame                        |               | 1    |
| 59  | bottom plate                            | Q480-00-026   | 1    |
| 60  | Inner hexagon bolt and spring gasket    | M6*30         | 2    |

| No. | Description                              | Specification | Qty. |
|-----|------------------------------------------|---------------|------|
| 61  | frame right board                        | Q480-00-042   | 1    |
| 62  | Spring                                   | Ø22           | 1    |
| 63  | spring plate                             | Q480-00-032   | 1    |
| 64  | external hexagon bolt                    | M8*30         | 3    |
| 65  | lifting shaft                            | Q480-00-036   | 1    |
| 66  | wheel                                    | Ø200*Ø18      | 1    |
| 67  | pointer                                  | Q480-00-025   | 1    |
| 68  | internal hexagon screw and spring gasket | M8*25         | 2    |
| 69  | Control panel                            |               | 1    |
| 70  | water tank board                         | Q480-00-028   | 1    |
| 71  | switch                                   | LAY37 (PBC)   | 1    |
| 72  | drawstring for water tank                |               | 1    |
| 73  | handle cover                             | Ø25           | 2    |
| 74  | Grip handles                             | Q480-00-019   | 2    |
| 75  | throttle lever assembly                  |               | 1    |
| 76  | Flange nut                               | M6            | 2    |
| 77  | external hexagon bolt and spring gasket  | M8*12         | 9    |
| 78  | Limited plate                            |               | 1    |



***MechMaxx***

[info@mechmaxx.com](mailto:info@mechmaxx.com)